
## RETENSION ALL BOLTS AFTER 8 hrs WORKING



\* Grease bearings weekly. Do not over grease as seals may be damaged

## NOTE ITEMS 2 TO 9 INCL. ARE SUPPLIED AS TWO ASSMEBLIES

- 1. Remove existing bearings, washers, spacers and hardware.
- 2. Ensure stars are central on axle, knock them along if necessary.
- 3. Slide crown slinger (1) onto each end as shown.
- 4. Fit bearing asssemblies to each end ensuring bearing sits against slinger.
- 5. Bolt one end of gang assembly to gang frame ensuring slot in item 4 faces down and bearing is to rear of gang frame.
- 6. Bolt other end together, if holes do not line up stretch the gang frame to allow bolts to fit.

,	ACCV THOTOLIGHTONIC				
	REF	QTY	PART No	DRG SIZE	DESCRIPTION
	1	2	HA3400		CROWN SLINGER
	2	1	HA3371		BRACKET RIGHT HAND
	м	1	HA3381		BRACKET LEFT HAND
	4	2	HA3372		SPACER PLATE
	5	2	BE114FL		FLANGED HOUSING
	6	2	BE114UCR3		BEARING - UC207-20R3
	7	4	B016M50CUP		M16 X 50 CUP HEAD SQUARE NECK BOLT
	8	4	NU16MZP		M16 NUT
	9	4	WA16MS		M16 SPRING WASHER
	10	4	NU12MZP		M12 NUT
	11	4	WA12MS		M12 SPRING WASHER
	12	4	B012M40		M12 X 40 BOLT
	13	4	WA12MF		M12 FLAT WASHER

AGNASTER 2067 MARSHALL ST. COLLIE WA 6225

ASSY INSTRUCTIONS HARROW BRG UPGRADE AI1051